


Справ. N	Перв. прим.



X1:1		EXPANCTION CONN1
1		
2	+5V	
3	GND	
4		
5		
6		
7		
8	GND	
9	+D09	
10	+D05	
11		
12		
13	+P00	
14	+P01	
15	GND	
16	GND	
17		
18	+3.3V	
19		
20		
21	+P011	
22	GND	
23	+P05	
24	+P06	
25		
26		
27		
28		
29		
30		
31		
32		
33	GND	
34	GND	
35		
36	+5V	
37		
38		
39		
40		

EXPANION CONN2		X91	
1	GND		
2	GND		
3	-3.3V		
4			
5	PC3		
6	PC4		
7	PC5		
8	PC6		
9	PC7		
10	PC0		
11	PC1		
12	PC2		
13	PD2		
14	PD6		
15	PD3		
16	PD5		
17	PD4		
18	PD4		
19	GND		
20	GND		
21	RESET		
22	P01		
23	PC12		
24	PC15		
25	PC8		
26	PC13		
27	PC9		
28	PC14		
29	PC11		
30	PC10		
31			
32			
33			
34			
35			
36			
37			
38	-5V		
39	GND		
40	GND		

[illegible]